

AUTO INSERTION MACHINE PARTS

PANASERT

NO	PARTS NO	PARTS NAME
1	432106	SPRING
2	1353005	LEVER
3	1518003	CUTTER
4	6315017	STOPPER
5	0104021	NUT
6	0104023	BRACKET
7	0104024	LEVER-5
8	0104025	LOCKTING PIN
9	0104026	LOCKTING PIN
10	0105005	SCRAP HOLDER
11	0105006	INSULATION WASHER
12	0105009	PIPE
13	0105013	TUBE
14	0105204	LINER-(7.5) (10.0)
15	0105205	LEVER-(5.0) (10.0) (12.5)
16	0105211	CLINCH BASE
17	0105211-1	CLINCH BASE
18	0105504	TUBE HOLDER
19	0109036	STOPPER
20	0110004	BLOCK
21	0112010	ROLLER-1
22	0112020	ROLLER SHAFT-1
23	0112030	ROLLER-2
24	0112085	PLATE STEEL
25	0112086	PLATE STEEL
26	0112088	ROLLER SHAFT-2
27	0118151	CUTTER CLINCH
28	0118152	CLINCH BASE
29	0180033	ROD
30	0217009	PIN
31	0217012	RACK
32	0217019	PIN
33	0217105	ROD
34	0233062	PIN
35	0233101	PIN
36	0234014	PIN
37	0234033	LEVER
38	0234204	ROD SHAFT
39	0244015	PIN
40	0273003	CUTTER CLINCH
41	0273003J	CUTTER CLINCH

42	0273004	CUTTER CLINCH
43	0273006	CLINCH BASE
44	0273007	CLINCH BASE
45	273008	PIN
46	0273016	PIN
47	0273020	PIN
48	0408005	PLATE
49	0408007	PIN
50	0408010	ROLLER
51	0408011	SPRING
52	0408012	PIN
53	0408013	BUSHING
54	04160041	CUTTER-2R (5.0)
55	04160041G	CUTTER-2R (5.0)초경
56	04160042	CUTTER-2L (5.0)
57	04160042G	CUTTER-2L (5.0)
58	0416008	PISTON
59	0416010	SPRING
60	0416012	PUSHER (B)-5.0
61	0416012	PUSHER
62	0416013	INSERTION GUIDE-5.0
63	0416017	SPRING (0416010)
64	0416020-2	LEVER-1 (5.0)
65	0416021	LEVER-2 (5.0)
66	0416055	BUSHING
67	0416114	PUSHER (B)-5.0
68	0416115	LEVER-1 (5.0)
69	0418001	CLINCH BASE-5.0
70	0418001-1	CLINCH BASE개조
71	0418001-2	CLINCH BASE
72	0418002	CLINCH BASE
73	0418003	CUTTER CLINCH 2T
74	0418003	CUTTER CLINCH 3T-5.0
75	0418003G	CLINCH CUTTER 초경
76	0420050	SHAFT
77	0420076	TUBE
78	0422001	LEVER
79	0422002	STOPPER
80	0422003	PINION
81	0422004	BUSHING
82	04220121	STOPPER
83	04220131	RACK
84	0422015	PIN
85	0422024	PLATE
86	0422057	BLOCK
87	0422061	RACK
88	0422062	KEY
89	0422065	ROD
90	0422086	PIN
91	0422195	PLATE

92	0430022	BALL PUSHER
93	0430023	HOUSHING
94	0430026	GUIDE
95	0430036	BLOCK
96	0430037	RACK
97	0430040	SLIDE BLOCK
98	0430041	GUIDE
99	0431014	SPRING
100	0431015	SPRING
101	0431016	SPRING
102	04320022	BALL PUSHER
103	0432003	PISTON (10.0)
104	0432004	SPRING
105	0432006	ROLLER
106	0432007	PIN
107	0432008	LEVER-5.0
108	0432101	LEVER-10.0
109	0432102	PUSHER-10.0
110	0432102G	PUSHER 초경
111	0432193	INSERTION GUIDE-10.0
112	0432193T	INSERTION GUIDE 10m/m
113	0432608	CUTTER-1(5.0)
114	0432608G	CUTTER-1 초경
115	0455124	CUTTER-1(10.0)
116	0455124G	CUTTER-1 초경
117	0552002	PUSHER-L
118	0552003	SLIDER-L
119	0552003S	SLIDER-L (SET)
120	0552008	PUSHER-R
121	0552009	SLIDER-R
122	0552020T	CUTTER
123	0552021	CUTTER
124	0552021S	CUTTER SET
125	0552021T	CUTTER
126	0552022	GUIDE
127	0552022S	GUIDE SET
128	0552043	BENDING DIE
129	0552043G	BENDING DIE 초경
130	0553001	BUSHING ROLLER
131	0554004	PIN
132	0554006	CLINCH BASE
133	0554006T	CLINCH BASE
134	0554007	SUB CLINCH BASE
135	0554009	CUTTER CLINCH
136	0554009T	CUTTER CLINCH
137	0554015	LINK
138	0554022	PIN ROLLER
139	0554023	PIN
140	0555015	PIN
141	0555034	PIN

142	0564032	BALL GUIDE
143	0564056	PLATE
144	0564057	CYLINDER
145	0564058	PISTON
146	0564060	SLIDE
147	0565004	PIN
148	0565019	PLATE
149	0565046	SLIDER
150	1304001	CUTTER-1
151	1304005	LEVER
152	1304011	LEVER
153	1304022	BUSHING
154	1304025	SPACER
155	1304101	INSERTION GUIDE-5.0
156	1304104	LINER-5.0
157	1304106	CUTTER-2L
158	13041061	CUTTER-2R
159	1304122	LEVER-5.0
160	1304123	PUSHER-5.0
161	1306001	CUTTER CLINCH
162	1306101	CLINCH BASE-5.0
163	1306102	SPACER-5.0
164	1310032	PIN
165	1310033	PIN
166	1316046	PIPE
167	1316052	GUIDE
168	1316108	ROLLER
169	1321005	PIN
170	1321016	PIN
171	1322005	RACK GUIDE
172	1322007	BUSHING
173	1322012	STOPPER
174	1322014	SLIDE
175	1322015	GUIDE
176	1322016	BLOCK
177	1322019	LEVER
178	1331068	GUIDE
179	1331114	BLOCK
180	1353003	PIN
181	1353007	PLATE
182	1353013	BUSHING
183	1361004	CUTTER-2R (10.0)
184	1361004G	CUTTER-2R
185	1361005	CUTTER-2L (10.0)
186	1361005G	CUTTER-2L
187	1380009	LEVER
188	1380011	PIN
189	1380014	PIN
190	1380016	SHAFT
191	1380018	BLOCK

192	1380043	BLADE
193	1380045	BLADE
194	1503003	LINK
195	1503004	CONNECTOR
196	1503007	SHAFT
197	1503015	PIN ROLLER
198	1503020	BLOCK
199	1503021	BLOCK
200	1503023	BOLT
201	1505008	UPPER BLADE
202	1505009T	TAPE CUTTER(2)
203	1505029	BUSHING
204	1505030	PIN
205	1505032	PIN
206	1505047	TAPE GUIDE
207	1505057T	CUTTER
208	1505065	PISTON
209	1506007	PIN
210	1506026	ROLLER
211	1506027	PIN
212	1507004	PIN
213	1507006	BUSHING
214	1507009	GUIDE PLATE
215	1507014	PISTON
216	1507016	CHUCK CYLINDER
217	1507017	PLATE
218	1507018	STOPPER
219	1507019	PIN
220	1507021	PIN
221	15070211	PIN
222	1507022	SPRING
223	1507031	CHUCK
224	1507032	CHUCK
225	15071013	CHUCK
226	15071022	CHUCK
227	1508010	PISTON
228	1508018	GUIDE
229	1508020	LEVER
230	1508021	LEVER
231	1508022	BLOCK
232	1508025	BLOCK
233	1508102	CHUCK BODY
234	1510024	LEVER
235	1513018	CUTTER
236	1513018T	CUTTER
237	1513019	CLINCH BASE
238	1513019T	CLINCH BASE
239	1513020	CLINCH BASE
240	15130201T	CLINCH BASE
241	1513021	CUTTER CLINCH

242	1513021T	CUTTER CLINCH
243	1513022	CUTTER CLINCH
244	1513022T	CUTTER CLINCH
245	1513024	PIN
246	1518033	COTTER
247	1535002	ROLLER
248	1535003	PIN
249	1535005	PIN
250	1535006	WASHER
251	1535010	RTL ROLLER
252	1535011	PIN
253	15350172	PISTON
254	1535023	PIN
255	1535026	SPRING
256	1535031	PISTON ROD
257	1535032	PISTON
258	1535046	PIN
259	1535047	NUT
260	1535063	CAM LEVER-1
261	1535064	CAM LEVER-2
262	1535065	HOLDER
263	1535066	PIN
264	1545016	TAPE CUTTER
265	1545051	UPPER BLADE
266	1545052	CUTTER
267	1559021	LEVER
268	1559022	GUIDE
269	1559105	BLOCK
270	1585022	PLATE
271	1622063	HOLDER
272	2701061	PULLEY
273	6318127	CUTTER
274	6318128	PUSHER-A
275	6318327S	INSERTION GUIDE
276	6318834	LEVER-L
277	6318844	LEVER-R
278	6318889	PUSHER
279	6323001	CUTTER CLINCH
280	6323003	CLINCH BASE
281	N491C8-1	ABSORTION PLUG PIN
282	N491CR15	ABSORPTION RUBBER
283	N540MB0606DU	D-U BUSHING
284	N540MB0610DU	D-U BUSHING
285	N540MB0812DU	D-U BUSHING
286	N540MB1020DU	D-U BUSHING
287	N550MY5	Y PACKING
288	N550MY7	Y PACKING
289	N6410762460	BELT
290	N641125302696	BELT
291	N64142	BELT 1245

292	N6416705 M 25	BELT
293	N64190	BELT 2010
294	N641TU5655	BELT
295	N6442020	COUPLING
296	N65000	MOTOR BRUSH
297	N981SA13	HANDLE GREP
298	UP60403	PLUG
299	X002-037-1	TRANSFER LEVER
300	X002-037-2	TRANSFER LEVER
301	X002-043	PIN
302	X002-207	HERICAL COUPLING
303	X003-055	CYLINDER PISTON
304	X003-073	GUIDE SHAFT
305	X003-075	SPRING
306	X003-079	FEED PAWL-A
307	X003-080	FEED PAWL-B
308	X003-081	FEED PAWL-C
309	X003-082	PIN
310	X003-083	SPRING
311	X003-084	SPRING
312	X003-085	SPRING
313	X003-089	TURING LOCK
314	X003-091	PLATE
315	X003-127	ROLLER-B
316	X003-161	PUSHER
317	X003-167	PIN
318	X003-169	LINK
319	X003-178	CYLINDER BRACKET
320	X003-191	ROLLER
321	X003-192	COLLAR
322	X003-194	SHAFT
323	X003-237	STAY-A
324	X003-339-1	SPACER
325	X004-007	SPRING
326	X004-059	FIXED BLADE-A (35')
327	X004-059G	FIXED BLADE-A (35')
328	X004-060	FIXED BLADE-B (35')
329	X004-060G	FIXED BLADE-B (35')
330	X004-061	MOVING BLADE-A (35',45')
331	X004-061CKG	MOVING BLADE 초경-A (35',45')
332	X004-062	MOVING BLADE-B (35')
333	X004-062CKG	MOVING BLADE 초경 (35')
334	X004-065	SHAFT
335	X004-067	BUSHING-B
336	X004-068	SHAFT
337	X004-069	BOLT
338	X004-070	SPRING
339	X004-074	PIN
340	X004-075	ROLLER
341	X004-076	HOOK

342	X004-077	PUSHER
343	X004-105-3	PUSHER
344	X004-105-4	PUSHER RUBBER
345	X004-120	FULCRUM SHAFT
346	X004-128	LOWER END STOPPER
347	X004-131-1	INSERTION CHUCK BODY
348	X004-131-2	BUSHING
349	X004-134	FULLRUM SHAFT
350	X004-135	PIN
351	X004-136	SPRING
352	X004-137	PISTON
353	X004-142	CENTER STOPPER
354	X004-148	COLLAR
355	X004-150	SPRING
356	X004-152	PISTON
357	X004-153	CAM SPRING
358	X004-205	CYLINDER MOUNTING PIN
359	X004-213	BUSHING
360	X004-214	PIN
361	X004-250	CUTTER-B
362	X004-256	CUTTER
363	X004-256CKG	CUTTER
364	X004-279	SPRING
365	X004-284	TRANSFER CHUCK-A
366	X004-322	PIN
367	X004-324	BUSHING
368	X004-353	TUBE JOINT
369	X004-358	MOUNTING BRACKET (A)
370	X004-359	MOUNTING BRACKET (B)
371	X004-371-2B	CHUCK RUBBER
372	X004-371L	RUBBER
373	X004-372	INSERTION CHUCK CLINCHER
374	X004-373	INSERTION CHUCK CLINCHER
375	X004-374-1	TRANSFER CHUCK-C
376	X004-374-2	STOPPER RUBBER
377	X005-015	BEARING HOLDER
378	X005-072	SPRING
379	X005-152	GUIDE SHAFT
380	X005-156	GUIDE SHAFT
381	X005-157	BEARING HOLDER
382	X005-175	SPRING
383	X005-341	CAM FOR VALVE
384	X006-114	SPRING HOOK
385	X006-143	CYLINDER BRACKET
386	X006-219	HOUSHING CYLINDER
387	X006-221	SPRING
388	X006-222	B,K,T STOPPER
389	X00G04017K	LEAD CUTTER-A
390	X00G04018K	LEAD CUTTER-B
391	X017-009	HOOK

392	X019-006	FIXED BLADE-A (45')
393	X019-006CKG	FIXED BLADE-A (45')
394	X019-007	FIXED BLADE-B (45')
395	X019-007CKG	FIXED BLADE-B (45')
396	X019-009	MOVING BLADE-B (45')
397	X019-009G	MOVING BLADE 초경-B (45')
398	X019-026	PUSHER
399	X019-041	CHUCK LEVER-A
400	X019-042	CHUCK LEVER-B
401	X021-282	FULCRUM PIN
402	X026-023	SPRING HOLDER
403	X036-023	SPRING HOLDER
404	X036-024	COLLAR-B
405	X036-026	PUSHER
406	X036-030	SHOOT
407	X036-031	LEAD LINE GUIDE-A
408	X036-034	LEAD LINE GUIDE-B
409	X036-036	CUTTER-A
410	X036-036CKG	CUTTER-A
411	X036-037	TAPER CUTTER-B
412	X036-046	GUIDE CHUCK
413	X036-047	LEAD GUIDE PIN (0.7)-RH
414	X036-050	LEVER-A
415	X036-051	LEVER-B
416	X036-052	PACKING-A
417	X036-053	PACKING-B
418	X036-057	PISTON
419	X036-057-1	PISTON O-RING
420	X036-058	SPRING
421	X036-060	SHAFT
422	X036-068	TRANSFER CHUCK RUBBER
423	X036-090	TRANSFER CHUCK UNIT-A
424	X036-091	TRANSFER CHUCK UNIT-B
425	X036-091-1	TRANSFER CHUCK RUBBER
426	X036-111	TRANSFER CHUCK BODY
427	X036-112	CENTER PIN
428	X036-116	LEAD CUTTER-A
429	X036-117	LEAD CUTTER-B
430	X036-136	SPRING
431	X036-247	GUIDE PIN (RH6 NEW)-A
432	X044-001	GUIDE PIN (RH6,RH3)-B
433	X044-002	GUIDE PIN (RH6,RH3)
434	X044-003	SPRING (X044-090)
435	X044-005	SPRING HOLDER
436	X044-010	BLOCK
437	X044-024	PISTON
438	X044-027-2	JOINT
439	X044-031	PISTON
440	X044-151	GUIDE PIN GUIDE
441	X050-926	TAPER CUTTER(036-036)

442	X050-926CKG	TAPER CUTTER 초경
443	X050-926T	TAPER CUTTER
444	X055-903	NUT
445	X055-917	SPRING HOLDER
446	X803-270-1	SPACER
447	X803-270-2	SPACER
448	X803-365	SPRING
449	X803-369	RETAINER PLATE
450	X804-001	LEAD GUIDE PIN
451	X804-002	GUIDE PIN (RHU-0.8)
452	X804-004	SPRING HOLDER
453	X804-005	CARTRIGE
454	X804-007	NUT
455	X804-011	BLOCK
456	X804-014	BLOCK
457	X804-019	CONNECT BLOCK-A
458	X804-020	CONNECT BLOCK-B
459	X804-021	CONNECT BLOCK-C
460	X804-105	PUSHER
461	X804-128	STOPPER
462	X804-135	PIN
463	X804-143	GUIDE CHUCK(0.8)
464	X804-177	PUSHER RUBBER
465	X804-204	SET SCREW
466	X804-215	FULCRUM PIN
467	X804-229	PISTON
468	X804-233	TAPER CUTTER-A
469	X804-233G	TAPER CUTTER-A
470	X804-234	TAPER CUTTER-B
471	X804-235	LEAD CUTTER-A
472	X804-236	LEAD CUTTER-B
473	X804-237	LEAD LINE GUIDE-A
474	X804-238	LEAD LINE GUIDE-B
475	X804-239	PUSHER
476	X804-239-1	PUSHER O-RING
477	X804-240	SET SCREW
478	X804-273U	TRANSFER CHUCK UNIT-A
479	X804-274U	TRANSFER CHUCK UNIT-B
480	X804-334	FULCRUM SHAFT
481	X804-335	FULCRUM SHAFT
482	X804-337-2	SPRING
483	X804-338	LEVER
484	X804-340	PISTON
485	X804-341	INSERTION CHUCK (A)
486	X804-342	INSERTION CHUCK (B)
487	X804-502	GUIDE PIN (RHU-0.7)
488	X804-503-2	GUIDE CHUCK (0.7)
489	X804-507	PISTON
490	X805-009	SLIDER SHAFT
491	X805-174	SPRING

492	X805-441	CONNECTING SHAFT
493	X820-002	SHAFT
494	X820-004	BUSHING
495	X820-013	SPRING
496	X820-014	SPRING
497	X820-051	FIXED BLADE-A(35')
498	X820-051G	FIXED BLADE-A(35')
499	X820-052	FIXED BLADE-B(35')
500	X820-052G	FIXED BLADE-B(35')
501	X820-053	MOVING BLADE-A(35')
502	X820-053CKG	MOVING BLADE-A(35')
503	X820-054	MOVING BLADE-B(35')
504	X820-054CKG	MOVING BLADE-B(35')
505	X820-055	MOVING BLADE-C(35')
506	X820-055CKG	MOVING BLADE-C(35')
507	X820-067	MOVING BLADE-A(35')
508	X820-067CKG	MOVING BLADE-A(35')
509	X820-068	MOVING BLADE-B(35')
510	X820-068CKG	MOVING BLADE-B(35')
511	X821-005	CHUCK LEVER
512	X821-051	FIXED BLADE-A(45')
513	X821-051G	FIXED BLADE-A(45')
514	X821-052	FIXED BLADE-B(45')
515	X821-052G	FIXED BLADE-B(45')
516	X821-053	MOVING BLADE-A(45')
517	X821-053G	MOVING BLADE-A(45')
518	X821-054	MOVING BLADE-B(45')
519	X821-054CKG	MOVING BLADE-B(45')
520	X821-055	MOVING BLADE-C(45')
521	X821-055CKG	MOVING BLADE-C(45')
522	X821-061	CHUCK LEVER
523	X821-062	PUSHER
524	X821-064	HOOK
525	X821-067	MOVING BLADE-A(45')
526	X821-067CKG	MOVING BLADE-A(45')
527	X821-068	MOVING BLADE-B(45')
528	X821-068CKG	MOVING BLADE-B(45')
529	X821-072	FIXED BLADE-A(45')
530	X821-073	FIXED BLADE-B(45')
531	XLC-685	BEARING
532	XPD-214	BELT HOLDER
533	XPJ-26	PIN
534	XPJH-7212	PIN
535	XPJH-726	PIN
536	XPJH-7620	PIN
537	XUC-4	E-RING
538		
539	5533006	BRACKET-0553006
540	N50102	STEEL BALL(D=2)-N50102
541	N50104	STEEL BALL(D=4)-N50104

542	N50103	STEEL BALL (D-3)-N50103
543	N550S014	O-RING-N550S14
544	XLCMR104ZZ	BEARING-XLCMR104ZZ