

## AUTO INSERTION MACHINE PARTS



NO	PART NO	DESCRIPTION
1	CAI-302	BAR, SHEAR -LH
2	CAI-303	BAR, SHEAR -RH
3	CL-657J	COLLAR, ADJUSTING
4	CL-690J	SPACER
5	DIP-1988	SCREW, ADJUSTING
6	ED-10305	COVER, SWITCH
7	ED-10403	SWITCH, HEAD UP
8	GIS-748	O-RING
9	GR-266	BALL TRANSFER
10	GS-59	LOADER SENSOR
11	GS-5N	SENSOR PHOTO
12	G-TYPE ASS'Y	CENTERING UNIT ASS'Y (G-TYPE)
13	HPDI-601	CAM FOLLOWER
14	HPDI-969	VALVE FLOW CONTROL
15	NC21U2	NUT, LOCKING
16	NEF-47	RING, CONVEYOR CHAIN PIN RETAINING
17	NL-1062K	LOCK NUT TRUNNION
18	NL12M1	NUT, CHECK
19	NL-1305K	NUT, PULLEY LOCKING
20	NL-1330K	LOCK NUT, SCREW
21	NL-1374K	NUT, LEVER ARM SHOULDER
22	NL-13M1	NUT, MINDING(2)
23	NL-1441K	NUT, CHECK HEX
24	NL-16U1	NUT
25	NL-17U1	NUT, SCREW
26	NL-20U2	NUT, PISTON LOCKING
27	NL-24U2	LOCK NUT
28	PCI-1639	CAP LINK RETAINING
29	PCI-1786A	SEAT BALL UNIT
30	PCI-180	RAIL, STATIONARY
31	PCI-1808	RAIL, STATIONARY
32	PCI-187	RETAINER, KNIFE
33	PCI-188	PLATE, CLAMPING
34	PCI-189	SHIELD, BALL
35	PCI-192	WIPER, SLIDE
36	PCI-193	RETAINER, SLIDE
37	PCI-363	KNIFE, FIXED
38	PCI-363A	KNIFE, FIXED 초경
39	PCI-395	SCREW
40	PCI-492	WASHER, INSULATING(2)
41	PL-1002P	PIN,CLEVIS

42	PL-1055P	PIN, COTTER
43	PL-1426P	PIN
44	PL-3184P	PIN
45	PL-4196P	PIN, DRIVER
46	PL-4331P	PIN, LEVER BAR CONNECTING
47	PL-5802	PIN, SPRING
48	PL-5819P	PIN, DISPENSER INDEX WHEEL
49	PL-5894P	PIN, PAWL LOCK STOP ROLL
50	PL-5959P	PIN
51	PL-6499P	PIN, CLEVIS(2)
52	PL-6684P	SHAFT, ROCKER, VERTICAL(2)
53	PL-6821P	PIN
54	SL-10N10	SCREW, STATIONARY RAIL ADJUSTING
55	SL-11H11	SCREW, BLOCK
56	SL-11H15	SCREW, RULCRUM
57	SL-11H17	SCREW, ADJUSTING
58	SL-11N25	SCREW, LEVER STOP
59	SL-11S15	SCREW, SET
60	SL-11S5	SCREW, GEAR BINDING
61	SL-12N6	SCREW, COLLAR
62	SL-13H17	SCREW, VERTICAL SLIDE MOUNTING
63	SL-13H21	SCREW, PLATE MOUNTING
64	SL-13H9	SCREW
65	SL-15H9	SCREW, DISPENSER MOUNTING
66	SL-17N29	SCREW, INSERTER HOUSING LIMIT
67	SL-20S36	SCREW
68	SL-3D15	SCREW, SWITCH MOUNTING
69	SL-3H5	SCREW, RETAINER
70	SL-3H7	SCREW, HOUSING ADJUSTING & LOCKING
71	SL-3S7	SCREW, PIN
72	SL-7C9	SCREW, CLAMP(4)
73	SL-7H5	SCREW, COMPONENT STOP AND CUTTER
74	SL-7H7	SCREW, CYLINDER CAP
75	SL-7H9	SCREW, SHAFT CLAMP
76	SL-7N5	SCREW, GEAR
77	SL-7S3	SCREW, CUTTER KNIFE COLLAR
78	SL-7S5	SCREW, GUIDE
79	SL-8504V	SCREW, SPRING
80	SL-8687V	SCREW, COMPONENT GUIDE BRACKET
81	SL-8985V	SCREW, SPRING
82	SL-8S2	SCREW, COLLAR
83	SL-9156V	SCREW, CAP
84	SL-9191V	SCREW, COVER
85	SL-9214V	SCREW
86	SL-9239V	SCREW, CYLINDER MOUNTING
87	SL-9262V	SCREW
88	SL-9D29	SCREW, SWITCH
89	SL-9H13	SCREW, RAIL MOUNTING
90	SL-9H3	SCREW, CHIP BINDING
91	SL-9H5	SCREW, CHUTE GUIDE

92	SL-9N3	SCREW, CUTTING WHEEL
93	SL-9N5	SCREW, DRIVER WHEEL
94	SL-9N7	SCREW, SHAFT
95	SL-9S5	SCREW, TAPE GUIDE
96	SPGL-2665S	SPRING, GEAR SUPPORT LEVER
97	SPGL-2930S	SPRING, LEVER OVERRIDE
98	STA-25	RING SOLENOID PIVOT
99	TCF-496	RING, LOCK RETAINING
100	UA-3004	O-RING
101	UCSM-1018	SHAFT, DRIVER GEAR
102	UCSM-1065	PLATE, CONVEYOR CHAIN SIDE INSIDE
103	UCSM-1088	PLATE, CONVEYOR CHAIN SIDE OUTSIDE
104	UCSM-1090	PIN, CONVEYOR CHAIN
105	UCSM-110	HOUSING, CLUTCH
106	UCSM-111A	DRIVE CLUTCH
107	UCSM-111A	DRIVE CLUTCH 개조
108	UCSM-1170	STOP COMPONENT
109	UCSM-118	PIVOT, SOLENOID MOUNTING
110	UCSM-119	BASE
111	UCSM-1241	FULCRUM, DISPENSER INDEX DETENT ROLL LEVER
112	UCSM-125	BUSHING, DISPENSER INDEX DETENT ROLL
113	UCSM-1357	SHAFT
114	UCSM-1360	PLATE, CONVEYOR CHAIN MOVABLE INSIDE
115	UCSM-1361	PLATE, CONVEYOR CHAIN MOVABLE OUTSIDE
116	UCSM-142	SPRING, DISPENSER INDEX DETENT ROLL LEVER
117	UCSM-1507	LINK, SLOTTED
118	UCSM-1508+	LINK, PIN-ASSEMBLED
119	UCSM-1566	STOP COMPONENT
120	UCSM-160	KEY, DRIVEN GEAR
121	UCSM-1732	GUIDE, COMPONENT
122	UCSM-1747	BLOCK, CONTACT RAMP
123	UCSM-1804	STRIPPER, COMPONENT-RH
124	UCSM-1805	STRIPPER, COMPONENT-LH
125	UCSM-1816	STOP COMPONENT
126	UCSM-184	SHAFT, DISPENSER DRIVE
127	UCSM-1857	CONTACT LOWER UNIT
128	UCSM-1869	STOP, COMPONENT
129	UCSM-1972	FINGER, YIELD BODY CENTERING OUTSIDE
130	UCSM-1973	FINGER, YIELD BODY CENTERING INSIDE
131	UCSM-1973J	CENTERING FINGER
132	UCSM-1999	BLOCK, CHAIN SIDE PLATE SET-UP
133	UCSM-2001	PIVOT, SOLENOID MOUNTING
134	UCSM-2002	BASE, SOLENOID MOUNTING
135	UCSM-202	PIN
136	UCSM-202A	PIN, SOLENOID PIVOT
137	UCSM-209	PLATE, REDUCER DRIVER
138	UCSM-210	SHAFT, REDUCER DRIVER
139	UCSM-2112	COMPONENT GUIDE
140	UCSM-212	SHAFT, TAPE WHEEL DRIVE
141	UCSM-2128	GUIDE OUTSIDE

142	UCSM-2129	GUIDE INSIDE
143	UCSM-213	SHAFT, CONVEYOR CHAIN DRIVE
144	UCSM-2149	WHEEL, CUTTING OUTSIDE
145	UCSM-2150	WHEEL, CUTTING INSIDE
146	UCSM-2151	KNIFE, CUTTER
147	UCSM-2165	WHEEL, DISPENSER OUTSIDE
148	UCSM-2166	WHEEL, DISPENSER INSIDE
149	UCSM-2231	BAND, BRACKE
150	UCSM-2232	ANCHOR
151	UCSM-2308	BLOCK, UPPER CONTACT FRONT
152	UCSM-2309	BLOCK, UPPER CONTACT REAR
153	UCSM-2325	CONTACT, UPPER UNIT ASSEMBLY
154	UCSM-2392	ROLL, PRESSURE ASSEMBLY
155	UCSM-2527	ARM SHAFT OPERATING LEVER
156	UCSM-2606	SUPPORT BODY CENTERING PIVOT
157	UCSM-2606	SUPPORT, BODY CENTERING PIVOT
158	UCSM-2607	BASE, BODY CENTERING PIVOT SUPPORT
159	UCSM-2608	SPRING, COMPONENT LIFT
160	UCSM-2769	LEVER, DISPENSER INDEX DETENT ROLL ASSEMBLED
161	UCSM-2784	SHAET, DRIVEN SPROCKET
162	UCSM-2847	SPRING
163	UCSM-294A	COLLAR, CLUTCH STOP
164	UCSM-3110	BASE, BODY CENTERING PIVOT SUPPORT
165	UCSM-3116	PLATE, CONVERYOR CHAIN SIDE INSIDE
166	UCSM-3117	PLATE, CONVERYOR CHAIN SIDE OUTSIDE
167	UCSM-3118	PLATE, CONVEYOR CHAIN MOVABLE INSIDE
168	UCSM-3119	PLATE, CONVEYOR CHAIN MOVABLE OUTSIDE
169	UCSM-3123	TRACG CARRIER FRONT
170	UCSM-3124	TRACG CARRIER REAR
171	UCSM-3164	LEAD-IN CENTERING BODY-C
172	UCSM-3165	LEAD-IN CENTERING BODY-B
173	UCSM-3169	SHAFT, CONVEYOR CHAIN DRIVE
174	UCSM-3170	SHAFT, TAPE WHEEL DRIVE
175	UCSM-3185	DRIVER, CLUTCH
176	UCSM-3190	BASE, SOLENOID MOUNTINR
177	UCSM-3203	SHAFT, TOP SUPPORT
178	UCSM-3206	SHAFT, DRIVING
179	UCSM-3210	WASHER, WHEEL(2)
180	UCSM-3215	STOP, COMPONENT
181	UCSM-3217	SHAFT, AUXILIARY
182	UCSM-3220	WHEEL, COMPINENT GUIDE(2)
183	UCSM-3221	GEAR, DRIVEN
184	UCSM-3257	KEY, INDEX WHEEL
185	UCSM-3258	SCREW, SHOULDER
186	UCSM-3267	WASHER, WHEEL(2)
187	UCSM-3278	WASHER, CUTTER
188	UCSM-3300	INDEX, WHEEL
189	UCSM-3319	SUPPORT, COMPONENT LOWER
190	UCSM-3357	BEARING, FLANGED SLEEVE
191	UCSM-3362	KNOB, TOP

192	UCSM-3365	SOLENOID DISPENSER, REAR
193	UCSM-3367	SOLENOID, DISPENSER FRONT
194	UCSM-3387	SHAFT, DRIVEN
195	UCSM-3455	ROLLER, INDEXING
196	UCSM-3462	BODY CENTERING GUIDE
197	UCSM-3469	LEVER, INDEX
198	UCSM-3472	RECEIVER, THIN WALL STUD
199	UCSM-3500	WHEEL, CUTTING OUTSIDE
200	UCSM-3509	CUTTER, OUTSIDE
201	UCSM-3510	CUTTER, INSIDE
202	UCSM-3511	WHEEL, CUTTING INSIDE
203	UCSM-3511	WHEEL, CUTTING INSIDE
204	UCSM-3516	STOP, COMPONENT
205	UCSM-3530	CARRIER TRACK REAR
206	UCSM-3531	CARRIER TRACK FRONT
207	UCSM-3620	KNOB, BOTTOM
208	UCSM-3636	COUPLE PRESSURE ROLL-L
209	UCSM-3637	COUPLE PRESSURE ROLL-R
210	UCSM-3656	CHUTE GUIDE, FRONT - INSIDE
211	UCSM-3657	CHUTE GUIDE, FRONT - OUTSIDE
212	UCSM-3667	GUIDE, COMPONENT-INSIDE
213	UCSM-3668	GUIDE, COMPONENT-OUTSIDE
214	UCSM-367	BASE
215	UCSM-3676	STOP, COMPONENT
216	UCSM-3677	ROLLER
217	UCSM-3695	COLLAR SHAFT
218	UCSM-370	STOP, COMPONENT
219	UCSM-3756	STOP, COMPONENT
220	UCSM-3757	WHEEL, GUIDE-OUTSIDE
221	UCSM-3758	WHEEL, GUIDE-INSIDE
222	UCSM-3761	SPRING, GUIDE WHEEL SEPARATION
223	UCSM-3763	CHUTE, GUIDE REAR OUTSIDE
224	UCSM-3764	CHUTE, GUIDE REAR INSIDE
225	UCSM-3768	WHEEL, TAPE GUIDE INSIDE
226	UCSM-3769	WHEEL, TAPE GUIDE OUTSIDE
227	UCSM-3782	SPRING, CLIP
228	UCSM-3798	HOUSING, BODY CENTERING PIVOT
229	UCSM-3798-1	HOUSING BODY SHAFT
230	UCSM-3805	FINGER, YIELD BODY CENTERING - L & R
231	UCSM-3805-A	CENTERING UNIT ASS'Y (G-TYPE)
232	UCSM-3808	PLATE, TAPE MOUNTING UPPER
233	UCSM-3811	BRACKET, UPPER TAPE GUIDE
234	UCSM-3818	SPINDEL, TAPE
235	UCSM-3832	SHAFT, UPPER TAPE GUIDE
236	UCSM-3851	COLLAR FINGER
237	UCSM-3858	GEAR, FINGER
238	UCSM-394	STUD, PRESSURE ROLL
239	UCSM-4028	PLATE, CONVEYOR CHAIN MOVABLE INSIDE
240	UCSM-4029	PLATE, CONVEYOR CHAIN MOVABLE OUTSIDE
241	UCSM-4031	PLATE, CONVEYOR CHAIN INSIDE

242	UCSM-4032	PLATE, CONVEYOR CHAIN OUTSIDE
243	UCSM-4053	STANDOFF, TAPE PLATE
244	UCSM-4110	FINGER, ADJUSTABLE BODY CENTERING(2)
245	UCSM-4113	SUPPORT, COMPONENT LOWER
246	UCSM-4139	PIN
247	UCSM-4150	INDEXING ROLLER PIN ASSEMBLY
248	UCSM-573	GUIDE WIRE
249	UCSM-588	SCREW, LEVER ARM SHOULDER
250	UCSM-669	ROLL, DISPENSER INDEX DETENT ROLL ASSEMBLED
251	UCSM-77A	WHEEL, DISPENSER INDEX
252	UCSM-79A	GUIDE, CHUTE-REAR-LH
253	UCSM-80A	GUIDE, CHUTE REAR RH ASSEMBLY
254	UCSM-878A	GUIDE, CHUTE FRONT LH ASSEMBLY
255	UCSM-879A	GUIDE, CHUTE FRONT RH ASSEMBLY
256	UCSM-886	PIN, HOUSING FULCRUM
257	UCSM-951	SUPPORT, COMPONENT LOWER
258	UCSM-955+	HOUSING, BODY CENTERING PIVOT
259	UCSM-969	SPRING, FINGER RETURN
260	UCSM-979+	LEVER, DISPENSER INDEX DETENT ROLL ASSEMBLED
261	UEF-504	O-RING
262	UFFM-78	BUSHING, FRAME
263	UGMS-42	BELT, TIMING (390L*050)
264	VC1M1613	CAM
265	VCD-10	GUIDE, SLIDE BRACKET
266	VCD-107A	BLOCK, SHEAR
267	VCD-108A	BLOCK, SHEAR
268	VCD-109	WHEEL, INDEXING
269	VCD-11	HOUSING, BEARING
270	VCD-1142	PLATE
271	VCD-117	BUSHING, INSIDE FORMER
272	VCD-118	SCREW, INSIDE FORMER
273	VCD-119	GUIDE, OUTSIDE FORMER L.H
274	VCD-120	GUIDE, OUTSIDE FORMER R.H
275	VCD-1208	CAM, SWITCH ACTUATING
276	VCD-128	BLOCK, ADJUSTING SCREW
277	VCD-1331	PAWL, WHEEL POSITIONING
278	VCD-1332	FULCRUM
279	VCD-1359AB	DRIVER END코팅
280	VCD-1360AB	DRIVER END코팅
281	VCD-1361	CHIP INSIDE FORMER
282	VCD-1362	CHIP INSIDE FORMER
283	VCD-1497A	BAR, SHEAR -LH
284	VCD-1499A	BAR, SHEAR -RH
285	VCD-152	JACKSHAFT, MOTOR
286	VCD-1578	BRACKET, LOWER HOUSING-RH
287	VCD-1579	BRACKET, LOWER HOUSING-LH
288	VCD-158+	PLATE
289	VCD-1637+	BAR DRIVER ASS'Y (7.5MM)
290	VCD-1638	COVER, HOUSING TOP
291	VCD-1639	CAP, LINK RETAINING

292	VCD-1642+	BLOCK BALL RETAINING REAR
293	VCD-1643+	BLOCK BALL RETAINING
294	VCD-1662	LINK, DRIVER
295	VCD-1663	KNIFE, MOVING
296	VCD-1664	ROD PISTON
297	VCD-1665	CAP CYLINDER
298	VCD-1666	PISTON
299	VCD-1670	CYLINDER CUTTER
300	VCD-1688	SLIDE FIXTURE INDEXING
301	VCD-1689+	PULLEY, CUT/CLINCH DRIVEN ASSEMBLED
302	VCD-1697	BUMPER
303	VCD-1705	COVER BALL SCREW
304	VCD-1753	NUT STOP PISTON
305	VCD-1777	PIN, DRIVING LEVER LINK
306	VCD-1778	PIN LEVER FULCRUM
307	VCD-1785	CUSHION, BALL SEAT
308	VCD-1786A	SEAT, BALL UNIT ASSEMBLY
309	VCD-1787	SEAT, BALL RETAINING
310	VCD-183	LEVER, GEAR SUPPORT
311	VCD-184	BLOCK, GESR SUPPORT LEVER
312	VCD-1862	BAR INSERTER SUPPORT
313	VCD-1873	PIN, CLEVIS CONNECTING
314	VCD-1875	BRACKET
315	VCD-1877	GEAR, DRIVEN UNIT ASSEMBLY
316	VCD-1882	PIN, CYLINDRE TRUNNION
317	VCD-1883	BUSHING, CYLINDER TURNNION
318	VCD-1886	CLAMP, SCRAP TUBE
319	VCD-1891	TUBE, SCRAP -LH
320	VCD-1892	TUBE, SCRAP -RH
321	VCD-1893	BAR, DRIVER LEVER
322	VCD-1894	BUSHING, PAWL
323	VCD-1914	BUMPER, CLUTCH HOUSING LEVER
324	VCD-1915	LEVER CLUTCH MOVING
325	VCD-196	STOP, DRIVE LEVER - REAR
326	VCD-199	SCREW, LEVER STOP
327	VCD-2019	GASKET
328	VCD-2020	PIN, PLATE LOCATING
329	VCD-2047T	WASHER, SCREW
330	VCD-205	SPRING, INSIDE FORMER
331	VCD-2058	KNIFE, FIXED
332	VCD-2059	SHEAR BLOCK
333	VCD-2059	BLOCK, SHEAR
334	VCD-2060	FORMER, INSIDE -RH (5MM)
335	VCD-2062G	END, DRIVER-LH (6MM) 초경
336	VCD-2063	FORMER, OUTSIDE -RH
337	VCD-2065	BAR, SHEAR-RH (5MM)
338	VCD-2066	FORMER, INSIDE -LH (5MM)
339	VCD-2068G	END, DRIVER-RH (6MM) 초경
340	VCD-2069	FORMER, OUTSIDE -LH
341	VCD-2071	BAR, SHEAR-LH (5MM)

342	VCD-2075	COVER, LOWER HOUSING-RH
343	VCD-2077	COVER, LOWER HOUSING-LH
344	VCD-2080+	BAR, DRIVER ASSEMBLED (4MM)
345	VCD-2080개조	BAR DRIVER ASS'Y (5MM)
346	VCD-21	PAD, BUFFER ELEVATOR
347	VCD-2103	GEAR, INSIDE DRIVE
348	VCD-2110	COVER UPPER HOUSING
349	VCD-2111	HOUSING, INSERT UPPER
350	VCD-2112	CUSHION DRIVE LEVER STOP
351	VCD-2124	SHAFT, COMPONENT GUIDE
352	VCD-2125	BRACKET, COMPONENT SHAFT-LH
353	VCD-2126	BRACKET, COMPONENT SHAFT-RH
354	VCD-2212	CUSHION DRIVE LEVER STOP
355	VCD-2213	BLOCK, DRIVER LEVER RETURN
356	VCD-2238	COUPLING, FLEXIBLE
357	VCD-232	SHAFT, ACTUATING LEVER
358	VCD-2327	CHIP, INSIDE FORMER-RH
359	VCD-2327G	CHIP, INSIDE FORMER-RH 초경
360	VCD-2328	CHIP, INSIDE FORMER-LH
361	VCD-2328G	CHIP, INSIDE FORMER-LH 초경
362	VCD-24	SHAFT, INDEXING WHEEL
363	VCD-2403	BLOCK CAM FOLLOWER
364	VCD-241	CAP, BEARING
365	VCD-2417	GUIDE, COMPONENT RH
366	VCD-2422	GUIDE, COMPONENT LH
367	VCD-246	CONNECTOR CYLINDER DRIVE
368	VCD-2464	HOUSING, INSERTER LOWER L.H
369	VCD-2466	HOUSING, INSERTER LOWER R.H
370	VCD-25	BLOCK, GEAR ADJUSTING
371	VCD-2569	SLIDE, POSITIONING
372	VCD-2570	PLATE, DISC LOCATING
373	VCD-2576	SHAFT, SERVO DEPTH STOP EXTENSION
374	VCD-2578	SHAFT, DEPTH STOP L.H
375	VCD-2579	SHAFT, DEPTH STOP R.H
376	VCD-2588	COLLAR, DEPTH STOP BRACKE
377	VCD-26+	SUPPORT, BEARING ASSEMBLED
378	VCD-2606	PIN, LOCKING
379	VCD-2607	BLOCK, GEAR SUPPORT LEVER
380	VCD-2608	LOCK, PAWL
381	VCD-2609	LEVER, RELEASE
382	VCD-266	PULLEY, CUT/CLINCH DRIVING
383	VCD-267	PULLEY, IDLER-DRIVING(2)
384	VCD-268	PULLEY, INSERT DRIVE
385	VCD-2688	TRACK CAM
386	VCD-2719	SLIDE, CAM
387	VCD-2723	PIN, RETAINING
388	VCD-2724	SPRING, BUMPER
389	VCD-28	ROD CONNECTING
390	VCD-2804	BUMPER CAM SLIDE
391	VCD-2805	PLATE, CAM FOLLWER



392	VCD-289	SWITCH, ACTUATOR
393	VCD-2913	SLIDE, DRIVE ROLL
394	VCD-2927	BLOCK, DRIVE SLIDE
395	VCD-2935	MOUNT, TRUNNION UNIT ASSEMBLY
396	VCD-2936	CLEVIS, CYLINDER ROD
397	VCD-2937	BRACKET, CABLE HOLDING
398	VCD-2940	SHAFT, ELEVATOR
399	VCD-2944	BLOCK, DEPTH STOP BRAKE LH
400	VCD-2945	BLOCK, DEPTH STOP BRAKERH
401	VCD-2952	BRAKE, DEPTH STOP LH
402	VCD-2953	BRAKE, DEPTH STOP RH
403	VCD-2957+	COLLAR, DEPTH STOP ACTUATOR
404	VCD-3006	GUIDE COMPONENT LOWER
405	VCD-3007	GUIDE COMPONENT LOWER
406	VCD-3009	SHAFT, DRIVE ROLL
407	VCD-3010	ROD, PISTON
408	VCD-3011+	ACTURATOR, DETENT L.H
409	VCD-3012+	ACTURATOR, DETENT R.H
410	VCD-3013+	BLOCK, LATCH SUPPORT ASSEMBLED
411	VCD-3015	PLATE, SLIDE SUPPORT
412	VCD-3032+	ACTURATOR, DETENT R.H
413	VCD-3105	SPACER, AIR CYLINDER
414	VCD-3106	PIN
415	VCD-3112	INSERT, DRIVE LEVER STOP
416	VCD-3113	COVER, MOTOR
417	VCD-3114	PULLEY, MOTOR
418	VCD-3115	PLATE, HOUSING BALL WEAR
419	VCD-315	FITTING
420	VCD-32	SHAFT, DRIVER LEVER LEFT
421	VCD-3233	HANDLE
422	VCD-3298	DRIVE BELT
423	VCD-33	SHAFT, DRIVER GEAR
424	VCD-3312	BRACKET,ADJUSTING SCREW
425	VCD-3361+	PLATE, HALL EFFECT
426	VCD-34	PIN, HOUSING GUIDE
427	VCD-3402	MOTOR ASS'Y
428	VCD-3493	HOUSING, BEARING
429	VCD-35	SHAFT, DRIVE LEVER RIGHT HEAD
430	VCD-3617	SUPPORT, SLIDE
431	VCD-3619	BLOCK, CAM FOLLOWER
432	VCD-3625	ROLL, DRIVER UNIT ASSEMBLY
433	VCD-3649	RETAINER
434	VCD-3678	BRACKET, DEPTH STOP MOTOR
435	VCD-3796	STEEL BALL(3/16)
436	VCD-3798	STEEL BALL(3/8)
437	VCD-38	LEVER, INDEXING DRIVER
438	VCD-39	GEAR, DRIVER
439	VCD-3919	BRACKET
440	VCD-3920	ACTUATOR
441	VCD-399	MOUNT, TRUNNION UNIT ASSEMBLY

442	VCD-42+	LEVER, INSERT DRIVE ASSEMBLED
443	VCD-4208	GUIDE, COMPONENT RH
444	VCD-4209	GUIDE, COMPONENT LH
445	VCD-4275	CYLINDER, CUT & CLINCH AIR
446	VCD-4328	WASHER, SCREW
447	VCD-4328	WASHER, SCREW(2)
448	VCD-4347	ELEVATOR SPEED CONTROL
449	VCD-4350	ELEVATOR CYLINDER
450	VCD-4351	BUMPER, ELEVATOR CYLINDER UP STOP
451	VCD-4354	SHAFT, ELVEVATOR
452	VCD-4510	MOUNT TRUNNION
453	VCD-4580	SPRING
454	VCD-4819	BRACKRT, TABLE CABLE
455	VCD-4848	NUT, PIN RETAINING
456	VCD-4997	MOUNT, TRUNNION UNIT ASSEMBLY
457	VCD-5002	SPEED CONTROL
458	VCD-5033	END, DRIVER-LH
459	VCD-5034	END, DRIVER-RH
460	VCD-5035	END, DRIVER-LH
461	VCD-5036	END, DRIVER-RH
462	VCD-5081	CAP, LINK RETAINING
463	VCD-515+	CUSHION, DRIVE LEVER STOP FRONT
464	VCD-5186	FITTING(1/4" TUBE*5/16THREAD)
465	VCD-5194	COVER, LOWER HOUSING-LH
466	VCD-5195	COVER, LOWER HOUSING-RH
467	VCD-52	STUD, IDLER PULLEY
468	VCD-5249	PIN, PLATE LOCATING
469	VCD-5250	PIN PLATE LOCATING
470	VCD-5425	BAR INSERTER SUPPORT
471	VCD-549	PULLEY
472	VCD-549	PULLEY, SWITCH LEVER DRIVE
473	VCD-663+	PLATE, VERTICAL SLIDE-RH ASSEMBLED
474	VCD-664+	PLATE, VERTICAL SLIDE-LH ASSEMBLED
475	VCD-669	HANGER, BAR SUPPORT
476	VCD-671	HOLDER, SHEAR BLOCK-L.H
477	VCD-672	HOLDER, SHEAR BLOCK-R.H
478	VCD-6878	GUIDE RIGHT END
479	VCD-689	SLIDE, MOVING
480	VCD-7	PLATE, ADAPTOR
481	VCD-708	GUIDE, HORIZONTAL SLIDE
482	VCD-710	SLIDE, VETICAL-RH
483	VCD-710	SLIDE, VETICAL-RH (빠크라이트)
484	VCD-711	SLIDE, VETICAL-LH
485	VCD-711	SLIDE, VETICAL-LH (빠크라이트)
486	VCD-712+	BRACKET, HORIEDNTAL SLIDE L.H ASSEMBLED
487	VCD-713+	BRACKET, HORIEDNTAL SLIDE R.H ASSEMBLED
488	VCD-72	BLOCK LEVER FULCRUM
489	VCD-734	PIN, PLATE LOCATING
490	VCD-746	RETAINER, INSIDE FORMER SPRING
491	VCD-822A	FORMER, OUTSIDE-RH

492	VCD-823A	FORMER, OUTSIDE-LH
493	VCD-860N100-1	BOARD HALL EFFECT SENSOR
494	VCD-97+	PLATE, FRONT STOP ASSEMBLED
495	VCD-976+	CARRIER, SLIDE-LH(VCD-5067)
496	VCD-977+	CARRIER, SLIDE-RH(VCD-5068)
497	VCD-987	BAR STOP ADJUSTING
498	VCD-988	EXTENSION DEPTH STOP BAR
499	VCDJ-0200-096	LEVER TOOLING PIN
500	VCDJ-0200-097	TOOLING PIN
501	VCDJ-5503	END DRIVER L
502	VCDJ-5504	END DRIVER R
503	VCDJ-6326	HOLDER BLOCK
504	VCDJ-6328	GUIDE CENTER
505	VCDJ-6352	SHEAR BLOCK
506	VCDJ-6353	HOLDER
507	VCDJ-6376	BAR RIGHT END
508	VCDJ-6377	BAR RIGHT END GUIDE
509	VCDJ-6378	GUIDE RIGHT END
510	VCDJ-6850	TUBE GUIDE
511	VCIM-1536	STOP, DRIVE LEVER
512	VCIM-1590	CLIVES CYLINDER ROD GUIDE
513	VCIM-1613	CAM, SWITCH ACTUATOR(2)
514	VH201D80	SCREW
515	WBT-1092	BUSHING, LEVER SPACING
516	WL-1226T	WASHER, FULCRUM PIN THRUST
517	WL-129T	WASHER, SCREW
518	WL-13T	WASHER, SCREW
519	WL-1837T	WASHER, CYLIDNER MOUNTING SCREW(2)
520	WL-1863T	LOCK WASHER, SCREW
521	WL-1890T	WASHER, LOCKING
522	WL-2047T	WASHER, SCREW
523	WL-2343T	BUMPER, OUTSIDE
524	WL-2391T	WASHER, CONVEYOR CHAIN PIN
525	WL-2396T	WASHER, GEAR SPACER
526	WL-3000T	WASHER, PLAIN(4)
527	WL-3002T	WASHER, SCREW
528	WL-3004T	WASHER, MOUNTING SCREW(4)
529	WL-3008T	WASHER, SCREW(2)
530	WL-3051T	WASHER, HANGER MOUNTING SCREW(4)
531	WL-394T	WASHER, MOUNTING SCREW(2)
532	WL-959T	WASHER, STOP SCREW
533	XF402A2	CLEVIS ROD CYLINDER GUIDE
534	XF406D16	REPAIR KIT
535	XF406D17	REPAIR KIT
536	XF900A007	"O"RING, FITTING
537	XF900A011	O-RING
538	XF900A026	O-RING
539	XF900A112	O-RING
540	XF900A114	O-RING
541	XF900A216	"O"RING, PISTON SEAL

542	XF900A216	O-RING
543	XF900A220	O-RING
544	XH110F13	SPRING,PAWL EXT
545	XH200C3	SCREW, MOUNTING BASE
546	XH200C45	SCREW, BRACKET(2)
547	XH200E2	SCREW, BRACKET MOUNTING
548	XH201A304	SCREW, BEARING
549	XH201A52	SCREW, CYLINDER MOUNTING
550	XH201C105	SCREW, BRACKET MOUNTING(2)
551	XH201C2	SCREW, SLIDE WIPER
552	XH201C21	SCREW, LINK PIN BINDING
553	XH201C22	SCREW, ACTUATOR
554	XH201C25	SCREW, GUIDE BLOCK MOUNTING
555	XH201C41	SCREW, MOUNTING
556	XH201C42	SCREW, BUMPER MOUNTING
557	XH201C45	SCREW, BLOCK
558	XH201C46	SCREW, MOUNTING HANGER
559	XH201C50	SCREW, PLATE MOUNTING - LOWER
560	XH204A24	SCREW, COMPONENT STOP & DEFLECTOR
561	XH204A53	BELT, SWITCH DRIVING TIMMING
562	XH301 A05-X50	KEY, GEAR
563	XH301 A05-X75	KEY, GEAR
564	XH400F99	SCREW, LEVER HOLDING
565	XH400J32	SCREW
566	XH601A8	CLAMP, PULLEY
567	XH603A8	NUT, STUD
568	XH604A5	NUT (10-24*3/16)
569	XH701C9	TAPE PIN, CLUTCH DRIVER (3/4"L X 141 DIA)
570	XH703B115	PIN, DRIVE LEVER
571	XH704A99	PIN, DETENT ROLL LEVER SPRING
572	XH704B81	PIN
573	XH704B83	SPRING PIN
574	XH705B104	SHAFT, ROCKER, HORIZONTAL(2)
575	XH705B49	PIN, HOUSING FULCRUM
576	XH705B74	PIN, INDEXING ROLLER
577	XH901B1	RETAINING RING, EXTERNAL(2)
578	XH901B3	RETAINING RING, EXTERNAL PUSH ON
579	XM100D123	SPRING, POSITIONING SLIDE
580	XM100F73	SPRING, COMPRESSION
581	XM110F13	SPRING
582	XM204A44	BELT, TIMING
583	XM204A58	BELT
584	XM204B11	BELT, TIMING (322L*050)
585	XM204B2	BELT TIMING(L) (150L*050)
586	XM204B20	BELT, TIMING(600L*050)
587	XM204C54	BELT
588	XM221C30-X500	PULLEY, TIMING BELT
589	XM301A05-X50	KEY, GEAR(3)
590	XM301A05-X75	KEY WHEEL INDEXING
591	XM301A2-X625	KEY, ADJUSTABLE DRIVE PLATE

592	XM-400J32	SCREW, COLLAR
593	XM500C6	BEARING, CUTTING WHEEL SHAFT(2)
594	XM503B1	BEARING, SCREW FLOATING
595	XM510G1	BEARING, SCREW FIXED
596	XM542N3	CAM FOLLOWER
597	XM543A100	BEARING, THRUST NEEDLE
598	XM544W1	WASHER, BEARING THRUST
599	XM560A3	ROD END
600	XM561A3	ROD END
601	XM561A4	END CONNECTING ROD
602	XM601A11	COLLAR, SHAFT
603	XM601A3	COLLAR, SPLIT
604	XM601A6	CLAMP, COUPLING
605	XM601A8	CLAMP, COUPLING MOTOR SIDE
606	XM601A9	CLAMP, PULLY
607	XM601F5	COLLAR SPLIT
608	XM652B259	BUSHING, FRAME SHAFT
609	XM652B81	BUSHING, SHAFT
610	XM658A2	BEARING, NYLINER(2)
611	XM659B375	BEARING(NYLINER)
612	XM720 M3	CLUTCH, ROLLER OVERRUNNING
613	XM720B2	CLUTCH, LEVER
614	XM720L2	CLUTCH, ROLLER
615	XM924C2	KNOB, DISPENSER SHAFT